

FENIX 2+ Vaporizer

USER MANUAL


Thank you for purchasing the Fenix 2+ vaporizer!

In order to ensure safe use, please read all instructions and safety warnings before operating. Failure to follow instructions may result in injury and may void your warranty.


Key Features

- Air Heating
- Stainless Steel Air Path
- 4800 mAh Battery
- Removable & Titanium Chamber
- 3-7 Minutes Working Time Adjustable

Fenix 2+ Vaporizer Overview




Includes




Important Usage Tips

- Rapidly press power button **5 times** On/Off with Vibration feedback.
- Press and hold power button and “-” button simultaneously within **2 seconds** to change from Fahrenheit to Celsius degrees or from Celsius to Fahrenheit.
- Working time setting, hold power button in **2 seconds** until cursor position under SET of timer, press control button +/- to adjust working time from 180 to 420 seconds.
- 160-221°C** Temperature reached with Vibration Feedback.
- Display indicates temperature information, battery status, duration timer.
- Quick battery check : one hit on power button when device is off , the icon on screen will show remain battery level.


How To Load With Dry Herb




Display Indication



How To Remove Heating Chamber



Load/RemoveThe Mouthpiece Components



Charging Instructions

- Battery capacity **4800 mAh**, USB-C charging, **5V/2A** suggested.
- Initially charge the Fenix 2+ for **3 hours**. The battery will stop charging when the icon is full.
- When battery level is low, charge battery with included USB-C cable to compatible wall charger. Low battery level will be indicated with icon .
- Do not use Fenix 2+ while charging.



FENIX Vaporizer – Leading the Industry with Patent Air Heating Technology

- FENIX NEO • FENIX 2 MAX • FENIX MINI+
- FENIX PRO • FENIX MINI • FENIX CLASSIC



Email: info@fenixvaporizer.com

E-mail Address: www.fenixvaporizer.com